

INSTALLATION INSTRUCTIONS

DRANJER™ JR15

Retrofit Floor Drain Model - Large

The Dranjer™ JR15 is for large floor drains. The unit fits underneath the existing strainer plate and is held in place by friction (pinched between the strainer plate and the retaining ring) and by caulking.

JR15 is 5 1/8" in height and 6 1/4" in width. The flexible flange is 11" in diameter.

To Install the Dranjer™ JR15

1. Remove the strainer plate.
2. Clean the retaining ring and the edge of the strainer plate.
3. Lay a bead of silicon caulking around the rim of the retaining ring.
4. Hold the JR15 under the strainer plate. Allow enough slack in the flexible flange so that the unit hangs down about 1/4 inch.
5. Place the strainer plate and the JR15 back into the floor drain, pinching the flexible flange between the strainer plate and the retaining ring.
6. Stand on the strainer plate to set the Dranjer™ firmly in place.
7. Trim off the surplus flange leaving "tabs" on the flange to facilitate future removal and re-placement of the unit.
8. Leave a weight on the strainer plate until the silicon caulking has cured.
9. Pour a cup of water into the drain to fill the trap.

